

Quick Start Guide*

*See owner's manual for complete assembly and operating instructions and important safety information before using this product.

STEP 1



Remove Outer Basket.
Pull Easy-Grip Handle straight out. Do not press the Basket Release Button on the Fry Basket or it will separate from the Outer Basket.

STEP 2



Load Fry Basket.
Arrange the food you are cooking inside the Fry Basket.

STEP 3



Return Outer Basket to Unit.
Push the Outer Basket straight into the Unit. Do not press the Basket Release Button on the Fry Basket or it will separate from the Outer Basket.

STEP 4



Setting Time & Temperature.
Follow instructions specific to your recipe. See included recipe book.

STEP 5



Separating Fry Basket from Outer Basket.
Remove Outer Basket. Set Outer Basket on a secure, heat-resistant surface. Move Sliding Button Guard and press Basket Release Button gently.

Unpack all parts from the box and remove any clear or blue protective film on the components. Wash with warm soapy water before first use (only select accessories are dishwasher safe).

After the cooking cycle has ended, the Red Heat Light will disappear along with all other icons on the Digital Control Panel. The Blue Fan Icon will continue to blink while the Unit cools down. After 25–30 secs., the Unit will power OFF automatically.