

# Quick Start Guide\*

\*See owner's manual for complete assembly and operating instructions and important safety information before using this product.

## STEP 1



### Remove Outer Basket

Pull the Easy-Grip Handle straight out.

## STEP 2



### Load Outer Basket

Arrange the food you are cooking on top of the nonstick Fry Tray.

## STEP 3



### Return Outer Basket to Unit

Push the Easy-Grip Handle straight in, until it clicks.

## STEP 4



### Power Unit On

Set the Time and Temperature. Follow instructions specific to your recipe.

## STEP 5



### Remove Outer Basket

Set the Unit on a secure, heat-resistant surface. Use tongs to remove food.

### NOTE:

- Before plugging the **Power AirFryer XL** into a power outlet, make sure all packaging material is removed from both outside and inside the Unit.
- After the cooking cycle has ended, the Digital Control Panel will shut off and the Unit's internal fan will run for an additional 10 secs. to cool down. After the Unit beeps five times, check to see if your food is fully cooked and transfer to a serving dish.

**Wash All Components Before First Use**