

Quick Start Guide*

PowerXL™

products that excel

AIR FRYER PRO X

* See owner's manual for complete assembly, instructions and important safety information before using this product.

STEP 1



Make sure the Drip Tray is in place. Press the Power/Start-Stop Button to turn on the PowerXL AirFryer ProX.

STEP 2



Arrange food on Crisper Trays and place the Crisper Trays inside the Unit.

STEP 3



Select one of the one-touch cooking presets to begin the cooking cycle. If using manual settings, select the time and temperature and then press the Power/Start-Stop Button.

STEP 4



The Unit will run after time has expired to cool off. The Unit will automatically shut down. Remove the Crisper Trays from the PowerXL AirFryer ProX while wearing oven mitts and enjoy!

Unpack all parts from the box and wash with warm, soapy water before first use (only accessories are dishwasher safe).