

Using the Fry Basket

1. With the latch off the Basket Handle (FIG. A), compress the Handle, place it between the slots on the Fry Basket, and release the Handle (FIG. B).
2. Close the latch on the Basket Handle over the top of the Handle (FIG. C), pressing down on the latch to ensure that it is completely secure (FIG. D).

3. The door cannot close with the Basket Handle still attached to the Fry Basket. Remove the Handle before closing.

NOTE: The Fry Basket can be inserted into the Unit by hand (only when Unit is cold), but the Basket Handle should ALWAYS be used to remove the Basket from the Unit (FIG. E).



FIG. A



FIG. B



FIG. C



FIG. D



FIG. E