

Quick Start Guide

PowerXL products that excel **AIR FRYER ELITE**

See owner's manual for complete instructions and important safety information before using this product.

STEP 1



Remove Basket

Place the Fry Tray in the Basket and push down until the Fry Tray clicks into place.

STEP 2



Arrange Food in Basket

Arrange the food you are cooking in the basket.

STEP 3



Return Basket to Appliance

Push the Handle straight in until it clicks.

STEP 4



Power Appliance On

Set the time and temperature. Follow instructions specific to your recipe.

STEP 5



Remove Basket and Food

Place the Basket on a secure, heat-resistant surface. Use tongs to remove food.

IMPORTANT: Unpack all parts from the box and remove any clear or blue protective film on the components. Wash with warm soapy water before first use (only select accessories are dishwasher safe).