

# Quick Start Guide

## Air Frying

# PowerXL™


products that excel

## TURBO AIR FRYER

See owner's manual for complete instructions and important safety information before using this product.

**IMPORTANT:** Unpack all parts from the box and remove any clear or blue protective film on the components. Wash with warm soapy water before first use (only select accessories are dishwasher safe).

### STEP 1



#### Insert Shallow Air Flow Racks or Mesh Fry Basket

Place the air fryer on a stable, horizontal, heat-resistant surface. Remove the Air Frying Lid from the Glass Bowl. Place food on your chosen air frying accessory and use the handles on the accessory to lower the accessory into the Glass Bowl.

### STEP 2



#### Attach Lid

Lower the Air Frying Lid onto the Glass Bowl, ensuring that the arrow on the front of the Air Frying Lid aligns with the arrow on the Glass Bowl.

### STEP 3



#### Set Cooking Settings

Plug the air fryer's power cord into a dedicated power outlet. Press the Power Button once. Select a preset cooking function or manually set your desired time and temperature. Press the Power Button again to begin the cooking cycle.

### STEP 4



#### Remove Accessories

When the cooking process is complete, the accessories will be hot. Remove the Air Frying Lid and use oven mitts to remove the accessories from the Glass Bowl.

# Quick Start Guide

## Rotisserie

# PowerXL™

products that excel

## TURBO AIR FRYER

See owner's manual for complete instructions and important safety information before using this product.

**IMPORTANT:** Unpack all parts from the box and remove any clear or blue protective film on the components. Wash with warm soapy water before first use (only select accessories are dishwasher safe).

### STEP 1



#### Insert Rotating Basket or Rotisserie Accessory

Place the air fryer on a stable, horizontal, heat-resistant surface. Remove the Air Frying Lid from the Glass Bowl. Place food on or in your chosen rotisserie accessory. Insert the accessory into the Rotisserie Socket in the right side of the Glass Bowl. Then, insert the accessory into the Rotisserie Socket on the left side of the Glass Bowl.

### STEP 2



#### Attach Lid

Lower the Air Frying Lid onto the Glass Bowl, ensuring that the arrow on the front of the Air Frying Lid aligns with the arrow on the Glass Bowl.

### STEP 3



#### Attach the Motor Drive

Open the cover of the Motor Drive socket on the right side of the Glass Bowl. Attach the Motor Drive to the socket and push the Motor Drive to lock it into place (do not overtighten).

### STEP 4



#### Set Cooking Settings

Plug the air fryer's power cord into a dedicated power outlet. Press the Power Button once. Select a preset cooking function or manually set your desired time and temperature. Press the Power Button again to begin the cooking cycle.

### STEP 5



#### Remove Accessories

When the cooking process is complete, the accessories will be hot. Remove the Air Frying Lid and use the Fetch Tool and oven mitts to remove the accessories from the Glass Bowl.