

Quick Start Guide

AIR FRY

PowerXL™

MICROWAVE AIR FRYER

See owner's manual for complete instructions and important safety information before using this product.

STEP 1



Before cooking food for the first time, preheat the appliance by operating the "Air Fry" function for at least 3 minutes to allow the manufacturer's protective coating of oil to burn off (the smell produced by this step is normal).

STEP 2



Open the door and place the Baking Pan on the Glass Tray or on the Air Fry Rack. The Air Fry Rack can be flipped so that food can be placed closer to or farther from the top heating element.

STEP 3



Close the door and press the Air Fry Button. Turn the Control Knob to select one of the presets. You can adjust the cooking time by pressing the Time Button and turning the Control Knob or the cooking temperature by pressing the Temp Button and turning the Control Knob. Press the Control Knob to confirm the settings, which begins the cooking process.

STEP 4



When the cooking cycle is complete, open the door and use oven mitts or potholders to remove your food from the appliance.

IMPORTANT: Unpack all parts from the box and remove any clear or blue protective film on the components. Wash with warm, soapy water before first use (**only the Glass Tray is dishwasher safe**).

For parts, recipes, accessories, and everything PowerXL, go to tristarcares.com or scan this QR code with your smartphone or tablet:



Quick Start Guide

MICROWAVE

PowerXL™

MICROWAVE AIR FRYER

See owner's manual for complete instructions and important safety information before using this product.

STEP 1



Before cooking food for the first time, preheat the appliance by operating the "Air Fry" function for at least 3 minutes to allow the manufacturer's protective coating of oil to burn off (the smell produced by this step is normal).

STEP 2



Open the door and place your microwave-safe food container or chosen cooking accessory on the Glass Tray.

STEP 3



Close the door and press the Micro Button. Turn the Control Knob to select one of the presets. You can adjust the cooking time by pressing the Time Button and turning the Control Knob or the microwave power level by pressing the Temp Button and turning the Control Knob. Press the Control Knob to confirm the settings, which begins the cooking process.

STEP 4



When the cooking cycle is complete, open the door and use oven mitts or potholders to remove your food from the appliance.

IMPORTANT: Unpack all parts from the box and remove any clear or blue protective film on the components. Wash with warm, soapy water before first use (**only the Glass Tray is dishwasher safe**).

Read all instructions before using this appliance. Only use provided accessories or accessories described in the instruction manual. **Do not use air fryer accessories while using the microwave function.** Inspect all accessories prior to use.

For parts, recipes, accessories, and everything PowerXL, go to tristarcares.com or scan this QR code with your smartphone or tablet:

